


# Little Bighorn

by **Carter**  
Enterprises

Accuracy Defined Through Design



## General Directions for Use:

### Travel Set Screw

To adjust the travel\*, slightly loosen the set screw just enough to relieve pressure, but without losing connection with the moon, to maintain setting. Rotate the half moon below the hook clockwise (as it appears in the diagram above) to *increase* the amount of travel, or counterclockwise to *decrease* the amount of travel. After adjusting the moon, retighten the set screw and test the release by hooking a string to a stationary object and test-firing the release. Caution: if the half moon is adjusted for insufficient travel, the release may fire prematurely and possibly cause damage.

*\*Travel refers to the degree the release must rotate in order to fire.*

### Moon Set Screw

The moon set screw is a micro adjustment feature allowing the archer to control the amount of sear engagement between the half-moon and the hook using finer adjustments. For decreased engagement, turn the set screw clockwise in *minimal increments* to desired amount of engagement. Note: When adjusting the moon set screw, use the same process for

testing the release as stated in “Travel Set Screw” section to avoid prefires and possible damage.

### Friction Enhancer

The Friction Enhancer works as a pulling post for the Little Bighorn release. Carter Enterprises recommends wrapping your thumb completely around the Friction Enhancer, thus insuring the release is at the proper angle when drawing back. Note: if the release is not at the proper angle when drawing back, there is a chance the release will prefire and possibly cause damage.

### Recommended Use

The Little Bighorn is a pure back-tension release. To load the jaw, simply flick the jaw open and close it around your D-loop or rope. To draw back, wrap your thumb completely around the Friction Enhancer, allowing the majority of pressure to transfer to the index finger and thumb. This allows the release to be drawn at an angle that will help avoid the possibility of prefire. Once you are at full draw, settle into your anchor, push your bow hand toward the target and lightly pull your release hand back, thus firing the release in one smooth motion.